


- SURFACE OF JOINT MUST BE SMOOTH AND FREE FROM DIRT AND LAITANCE BEFORE FIXING WATERSTOP.
- WATERSTOP MUST BE GLUED TO THE SURFACE WITH RECOMMENDED ADHESIVE.
- IN CASE OF SHOTCRETE APPLICATION WATERSTOP MUST ALSO BE SECURED AT POSITION WITH CONCRETE NAILS @ 12" MIN SPACING.

Hycrete details illustrate generic construction guidelines. They are intended for use by design/construction professionals, to assist in developing project-specific details. These should be modified where necessary to accommodate individual project conditions. The user maintains all responsibility for verifying the applicability and suitability of the technical service or information provided. Contact a Hycrete technical professional for assistance in project-specific requirements. Always refer to project specifications and local building codes for any special requirements.
 © 2009 Hycrete, Inc. All rights reserved. The right to utilize Hycrete details for commercial purposes is granted exclusively to contractors, architects, quantity surveyors, engineers, waterproofing consultants, and specification writers. Hycrete™ is a registered trademark of Hycrete, Inc.

LOCATION: ABOVE OR BELOW GRADE	DETAIL TYPE: WATER TANK		
POUR TYPE: CIP	APPLICATIONS: ELEVATED SLAB OVER UNOCCUPIED SPACE.		
 Delivering Concrete Solutions	DRAWING TITLE: WATER /RETENTION TANK		
	462 BARELL AVENUE CARLSTADT NJ 07072 USA +1 (201) 386 8110 WWW.HYCRETE.COM	SEP 2009	DRAWING NUMBER: 7301001
		DRWN BY:FAZAL	CHKD BY:NHM
			NTS