


- SURFACE OF JOINT MUST BE SMOOTH AND FREE FROM DIRT AND LAITANCE BEFORE FIXING WATERSTOP.
- WATERSTOP MUST BE GLUED TO THE SURFACE WITH RECOMMENDED ADHESIVE.
- IN CASE OF SHOTCRETE APPLICATION WATERSTOP MUST ALSO BE SECURED AT POSITION WITH CONCRETE NAILS @ 12" MIN SPACING.

Hycrete details illustrate generic construction guidelines. They are intended for use by design/construction professionals, to assist in developing project-specific details. These should be modified where necessary to accommodate individual project conditions. The user maintains all responsibility for verifying the applicability and suitability of the technical service or information provided. Contact a Hycrete technical professional for assistance in project-specific requirements. Always refer to project specifications and local building codes for any special requirements.

© 2009 Hycrete, Inc. All rights reserved. The right to utilize Hycrete details for commercial purposes is granted exclusively to contractors, architects, quantity surveyors, engineers, waterproofing consultants, and specification writers. Hycrete™ is a registered trademark of Hycrete, Inc.

| | | |
|--|---|--|
| LOCATION: ABOVE OR BELOW GRADE | DETAIL TYPE: WATER TANK | |
| POUR TYPE: CIP | APPLICATIONS: ELEVATED SLAB OVER UNOCCUPIED SPACE. | |
|  Hycrete Delivering Concrete Solutions | DRAWING TITLE: WATER /RETENTION TANK | |
| | 462 BARELL AVENUE CARLSTADT NJ 07072 USA +1 (201) 386 8110 WWW.HYCRETE.COM | SEP 2009 DRWN BY:FAZAL CHKD BY:NHM |